Your mobile

one touch 112 one touch 113



This product meets applicable national SAR limits of 2.0 W/kg. The ific maximum SAR values can be found on page 16 of this use

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise ain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be ransmitting even if you are not making a phone call.

Prolonged exposure to music at full volume on the music player may damage

Prolonged exposure to music at tuli volunte on the human party of the listener's hearing. Set your phone volume safely. Use only headphones





Confirm an option (press the middle of the key) Activate/Deactivate LCD backlights (1) (long keypress in idle screen)

Access favorite contact(s) (2) (long keypress in idle screen) Profiles A

Organizer 🔻 Create message Alarm

Send call Access to call log (idle screen) Activate fake call (long keypress)

Power on/off the handset (long keypress) End call Return to idle

- A Left softkey

— 6 Right softkey

O + 0 In edit mode

- Short keypress: access the language list

6 From idle screen - Short keypress:

- Long keypress:lock/unlock the keypad

- Short keypress: change input methods

- Long keypress: access the Symbols table

(i) one touch 112/one touch 113 only.

• From idle screen

- Short keypress: #

- Long keypress: activate/deactivate the vibrator In edit mode

- Short keypress: - (space)

- Long keypress: add a word

5 → From idle screen

- Short keypress: dial '5' - Long keypress: switch on/off the torch

Idle screen icons

Battery charge level

Vibration alert: your phone vibrates, but does not ring.

Headset connected (2).

Call forwarding activated: your calls are forwarded

Alarm clock programmed. Voicemail message arrived

FM radio is on @

Unanswered calls

Roaming

Level of network reception

Silence mode: your phone neither rings nor vibrates.

Keypad locked

Stopwatch is active (2)

Ringtone alert (2)

Vibration and ringtone alert (2).

(1) one touch 112/one touch 113 only. (2) one touch 213 only.

Getting started

2.I Set-up

Removing and installing the back cover



Installing and removing the battery







Inserting and removing the SIM Card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

Charging the battery



Connect the battery charger to your phone and mains socket respectively

· The charging may take about 20 minutes to start if the battery is flat.

Be careful not to force the plug into the socket. Make sure the battery is correctly inserted before connecting the charger.

The mains socket must be near to the phone and easily accessible To access your voicemail, hold down the I we key. (avoid electric extension cables)

When using your telephone for the first time, charge the battery 3.3 Receiving a call fully (approximately 3 hours). You are advised to fully charge the battery(iii).

To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.

The charge is complete when the animation stops

2.2 Power on your phone

Hold down the * key until the phone powers on.

2.3 Power off your phone

Hold down the ** key from the idle screen.

Calls

Making a call

Dial the desired number then press the — key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the - key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the — key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail (1)

When you receive an incoming call, press the — key to talk and then hang up using the - key.

3.4 Available functions during the call

During a call, you can use your directory, short messages, etc. without losing your correspondent.

(1) Contact your network operator to check service availability.

Call register 😝 5

4 I Unanswered

In this menu, you can find the unanswered calls list.

4.2 Outgoing calls In this menu, you can find the outgoing calls list

4.3 Answered calls In this menu, you can find the answered calls list.

4.4 My numbers

Type in or modify your telephone number or the number to access your voicemail and confirm by pressing . Your telephone number is 6.1 Create SMS usually written on your SIM card.

4.5 Billing

You can access different items with this option: Amount, Duration.

4.6 Call settings

You can access a number of items with this option: Caller ID, Call waiting, Call forward, Answer mode, Call barring...

4.7 Call control (1)

The menu serves you the dual purposes of cost monitoring and controlling during a call by the settings of "By cost" and "By

(1) Depending on your network operator.

English - CIB22VAALAAB

5.1 Consulting your directory To access the **directory** from the idle screen, press the key and 8.1 Games (2) select the 🛐 icon from the menu.

5.2 Adding a contact

Select the directory in which you wish to create a file, press the "Options" softkey, select "Add contact" then .

Messages



From the main menu select "Messages" to create text message. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to "Drafts".



Specific letters (accent) will increase the size of the SMS, 8.5 Calculator this may cause multiple SMS to be sent to your recipient.

From the idle screen, select the icon menu 💸 and select the

Settings

function of your choice in order to customise your telephone: Display, Clock, Keys, Dictionary, More settings...

Directory.....

Games & Tools (2)

allows you to manage settings, in which you may set background audio and vibration alert.

8.2 Organizer

Once you enter this menu, there is a monthly-view calendar for you to keypress 🜟 key or Long keypress 5-4 key to deactivate it. keep track of important appointments, etc. Days with events entered will be marked.

8.3 Stopwatch

Stopwatch is simple application for measuring time with possibility to Your Alcatel phone may include some games. register several results and suspend/resume measurement

Your mobile phone has a built-in alarm clock with snooze feature.

Hold down the # key to get the decimal point. Confirm with the key or the left softkey

Converter

- (1) one touch 112/one touch 113 only. (2) one touch 213 only.
- (3) one touch 113/one touch 213 only.

8.7 Fake call

Protect yourself from annoying situations with the "Fake Call". In this menu, you can set "Caller's name", "Call time" and "Ring tone". When the timer reaches, the phone will ring and display like receiving a real phone call. Press — key, pretend answering a call, the screen will display just like have an ongoing call. Press ** key, pretend reject the call, the call will terminate automatically.

To light in darkness, you may activate "Torch" by below operations In idle screen, long keypress 5 sq key to activate the Torch light; short

Games (I)

9.I Game settings

It allows you to manage settings, in which you may set background audio and vibration alert.



Your mobile phone has a built-in alarm clock with snooze feature

(1) one touch 112/one touch 113 only ⁽²⁾ one touch 112 only

FM Radio (1) Your phone is equipped with an FM radio (9) with RDS functionality. You To write messages, there are two writing methods: and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual

My shortcuts.. (2) (3)

Access the shortcuts already programmed. To programme new shortcuts: select "Add" if you want to create a quick access to functions, Numbers, Channel list, etc.

Radio service. You can listen to it while running other applications.

Reprofiles......

With this menu, you may personalise ringtones for different events and environments



Contact your network operator to check service availability.

4 Services 3

(1) one touch 113/one touch 213 only (2) one touch 112/one touch 113 only.

one touch 213 only.

(4) The quality of the radio depends on the coverage of the radio station in that particular area.

can use the application as a traditional FM radio with automatic tuning - Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.

5 Latin input mode

 Predictive with the Zi mode; this mode speeds up the writing of your text. Write the word by pressing a key between 2 and 9 . Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys:

- O+ key in edit mode Short keypress: access the language list Long keypress; enter zero

 8^{-1} , 6^{-1} , 6^{-1} = Too -> 6^{-1} -> tomorrow

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2011 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

For more information about how to use the phone, please go to www.alcatelonetouch.com_to_download_complete_user_manual_ (English version only). Moreover, from the website you can also consult FAQ (English version only).

12

one touch 213















- Long keypress: enter zero

In edit mode

Tools (1)

Your Alcatel phone includes some games. Select "Game settings", it

Unit converter and Currency converter

manufacturer disclaims any liability for damage, which may result as a consequence temporary and not serious. of improper use or use contrary to the instructions contained herein. TRAFFIC SAFETY:

a real risk, even when the hands-free kit is used (car kit, headset...), drivers are

Do not drop, throw or bend your mobile phone. jested to refrain from using their mobile when the vehicle is not parked.

radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your phone emits electromagnetic waves that can interfere with TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the *BATTERY:

- the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure use of other chargers or batteries. that there is no problem:
- do not place your phone on top of the dashboard or within an airbag deployment - check with your car dealer or the car manufacturer to make sure that the
- dashboard is adequately shielded from mobile phone RF energy. CONDITIONS OF LISE

Switch the phone off before boarding an aircraft.

can interfere with other electrical or electronic devices, or equipment using radio

Switch the phone off when you are near gas or flammable liquids. Strictly obey all - Do not play or use a flashing-lights feature if you are tired or need sleep. signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any notentially explosive atmosphere

When the phone is switched on, it should be kept at least 15 cm from any medical - Play at the farthest distance possible from the screen device such as a pacemaker a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories without supervision

When replacing the cover please note that your phone may contain substances that could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY: manufacturer's recommended operating temperature range is -10°C to +55°C. We recommend that you read this chapter carefully before using your phone. The Over 55°C the legibility of the phone's display may be impaired, though this is

> Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourse

Do not paint it. When driving do not use your phone and headphone to listen to music or to the Use only batteries, battery chargers, and accessories which are reco TCT Mobile Limited and its affiliates and are compatible with your phone model.

> Remember to make back-up copies or keep a written record of all important switched off. information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing - Do not attempt to open the battery (due to the risk of toxic fumes and burns). lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your You are advised to switch off the telephone from time to to me to polimise its doctor before playing video games on your phone or enabling a flashing-lights feature Batteries must be disposed of in accordance with locally applicable environmental Tests for SAR are conducted using standard operating positions with the device As mobile devices offer a range of functions, they can be used in positions other than on your phone

Switch the phone off when you are in health care facilities, except in designated incorporate flashing lights on the phones. All persons should discontinue use and affiliates. areas. As with many other types of equipment now in regular use, mobile telephones consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the elihood of such symptoms, please take the following safety precautions:

- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on
- If your hands, wrists, or arms become tired or sore while playing stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional disco your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders

Prolonged exposure to music at full volume on the music player may damage CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones mended by TCT Mobile Limited and its affiliates

such laws and regulations, it may be strictly forbidden to take photographs and/or to applicable electrical specifications, a charger you purchased in one jurisdiction may be provided in the device, the lower its SAR value. record the voices of other people or any of their personal attributes, and duplicate not work in another jurisdiction. They should be used for this purpose only. or distribute them as this may be considered to be an invasion of privacy It is the *RADIO WAVES*

Observe the following precautions for battery use:

- Do not burn or dispose of a used battery in household rubbish or sto temperatures above 60°C.

Parents should monitor their children's use of video games or other features that use damaged batteries or those not recommended by TCT Mobile Limited and/or its highest SAR values under the ICNIRP guidelines for this device model are:



14

This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points and it their life:

- Municipal waste disposal centres with specific bins for these items of equipment Collection bins at points of sale.
- They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge All products with this sign must be brought to these collection points

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your risdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CHARCERS

tion or other jurisdiction(s) where you will use your mobile phone regarding. The chargers designed for your mobile phone meet with the standard for safety of interference on the network, the operating power of your mobile device is king photographs and recording sounds with your mobile telephone. Pursuant to information technology equipment and office equipment use. Due to different automatically decreased when full power is not needed for the call. The lower the Internet address: www.alcatelonetou.ch.com

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO not indicate the need for any special precautions for the use of mobile devices. They RADIO WAVES

the limits for exposure to radio waves (radio frequency electromagnetic fields), device away from the head and body. recommended by international guidelines. The guidelines were developed by an For more information you can go to www.alcatelonetouch.com independent scientific organization (ICNIRP) and include a substantial safety margin Additional information about electromagnetic fields and public health are available on designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg

regulations. Only use the battery for the purpose for which it was designed. Never transmitting at its highest certified power level in all tested frequency bands. The against your ear. In such circumstances the device will be compliant with the through our website: www.alcatelonetouch.com

Maximum SAR for this model and conditions under which it was recorded.				
Head SAR	GSM 900	one touch 112 one touch 113 one touch 213	1.2 W/kg	
		one touch 112	0.7 W/kg	

ne touch II3 06W/kg

ne touch 213 0.7 W/kg

GSM 900

Body-worn SAR testing has been carried out at a separation distance of 1.5 cm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved questions you may have. accessory ensure that whatever product is used is free of any metal and that it

An electronic version of this user guide is available in English and positions the phone the indicated distance away from the body.

The World Health Organization has stated that present scientific inform recommend that if you are interested in further reducing your exposure then you Before removing the battery from your phone, please make sure that the phone is Your mobile device is a radio transmitter and receiver. It is designed not to exceed can easily do so by limiting your usage or simply using a hands-free kit to keep the

the following site: http://www.who.int/peh-emf

Your telephone is equipped with a built-in antenna. For optimal operation, you sho avoid touching it or degrading it.

guidelines when used with headest or LISR data cable if you are using another accessory ensure that whatever product is used is free of any metal and that it Protection against theft (1) positions the phone at least 1.5cm away from the body.

·LICENCES

eZiText™ eZiText™ and Zi™ are trademarks of Zi Corporation and/or 71corporation its Affiliates

During use, the actual SAR values for this device are usually well below the values General information

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any

other languages according to availability on our server: www.alcatelonetouch.com

Your telephone is a transceiver that operates on GSM networks with 900 and 1800 MHz bands

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0.6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen This number allows your mobile telephone to be blocked preventing a third person. from using it, even with a different SIM card.

Disclaimer

17

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

(I) Contact your network operator for service availability.

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your 3) Modification or repair performed by individuals not authorised by • You are advised to switch off the telephone from time to time to original invoice

Batteries and accessories sold with your phone are also warranted
4) Inclement weather, lightning, fire, humidity, infiltration of liquids or • You are advised to fully charge () the battery for optimal against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice. In case of any defect of your phone which prevents you from normal

your phone with your proof of purchase. If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories provided by your country or jurisdiction. are entitled to a one (I) month warranty for the same defect. Repair In no event shall TCT Mobile Limited or any of its affiliates be liable for

or replacement may be carried out using reconditioned components This warranty covers the cost of parts and labor but excludes any

offering equivalent functionality.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

(1) The warranty period may vary depending on your country. (2) The life of a rechargeable mobile phone battery in terms of

conversation time standby time, and total service life, will depend

on the conditions of use and network configuration. Batteries

being considered expendable supplies, the specifications state that

you should obtain optimal performance for your phone during the

first six months after purchase and for approximately 200 more

I) Non-compliance with the instructions for use or installation, or **Troubleshooting......** with technical and safety standards applicable in the geographical area where your phone is used

2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited.

foods, chemical products, download of files, crash, high voltage,

TCT Mobile Limited or its affiliates or your vendor,

Your phone will not be repaired in case labels or serial numbers (IMEI) use thereof, you must immediately inform your vendor and present have been removed or altered.

corrosion, oxidation...

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty

indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages My phone has not responded for several minutes can be disclaimed by law. Some countries/states do not allow the Press the key exclusion or limitation of indirect, incidental or consequential • Remove the battery and re-insert it, then switch the phone back on damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

Before contacting the aftersales department, you are advised to follow

- optimise its performance
- operation
- Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

and carry out the following checks:

My mobile phone will not switch on Press - until the screen comes on

- · Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then turn your telephone back on

Clean your screen

- Use your mobile phone in accordance with the recommended conditions of use

My mobile phone turns off by itself

- Check that your keypad is locked when you are not using your mobile phone
- · Check the battery charge level

My mobile phone has a low level of autonomy

- hours) · After a partial charge, the battery level indicator may not be exact. · Make sure your mobile phone is connected to a network, and that
- My mobile phone will not charge properly Make sure that your battery is not completely discharged; If the battery is flat, it may take around 20 minutes to display the battery **Unable to receive incoming calls**
- charger indicator on the screen Make sure charging is carried out under normal conditions (0°C-+40°C)
- Make sure your battery is inserted. It must be inserted before plugging in the charger
- Make sure you are using an Alcatel battery and charger in the box Make sure that you have not barred certain calls When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

SIM card error

exact indication

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V or 18V compatible; the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

valid etc)

- Make sure you respected the complete charge timing (minimum 3 Make sure you have dialled a valid number and press the key
 - For international calls, check the country and area codes
- the network is not overloaded or unavailable Wait for at least 20 minutes after removing the charger to obtain an Check your subscription status with your operator (credit, SIM card
 - Make sure you have not barred outgoing calls

- Make sure your mobile phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit SIM card valid, etc.)
- Make sure you have not forwarded incoming calls

The caller's name does not appear when a call is received Check that you have subscribed to this service with your operator

Your caller has concealed his/her number

The sound quality of the calls is not optimal

You can adjust the volume during a call by means of the key

- I am unable to use the features described in the manual Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not dialled

- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a
 Switch on the backlight upon request. foreign country

I am unable to create a file in my directory

· Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)

My callers are unable to leave messages on my voicemail

- Contact your network operator to check service availability
- I cannot access my voicemail
- Make sure your operator's voicemail number is correctly entered in "My numbers"
- Try later if the network is busy

The icon is displayed on my standby screen

· You have saved too many short messages on your SIM card; delete some of them or archive them in the product memory

"No service"is displayed

You are outside of the network coverage area

I have already entered 3 incorrect PIN codes

· Contact your network operator to obtain the PUK code (Personal Unblocking Kev)

My mobile phone is frozen, can't power on

Make sure your battery is not completely used up or damaged;

- Remove your battery remove your SIM card then reinstall them to power on again, if still does not work;
- Hold down # key and press Power on/off key for a while to reset the phone.

All user phone data: contacts, messages and files will be



How to make your battery last longer Make sure you follow the complete charge time (minimum 3 hours) After a partial charge the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an

exact indication